

# PALLET

## Accessory Hook Install Instructions

WADDELL.

- 1.) Slide hook at an angle in-between the slats of the Pallet.
- 2.) Allow hook to rest flat on the top of the slat, the leg of the hook should be resting against the backside of the Slat directly above it.

