

PALLET

Pallet Magnetic Accessory Instructions

1. Install the base plate in-between the Pallet slats at an angle.
2. Allow the base plate to rest flat along the face of the slat.
3. Attach the magnetic accessory to the face of the base plate.

